

Quick start guide: Shure SLX2 handheld wireless transmitter

GETTING STARTED:

- To turn ON: Press and hold ON/OFF button on front of device for 2 seconds to turn ON (green light will turn on).
- To turn OFF: Press and hold ON/OFF button for 2 seconds to turn OFF (green light will turn off).
- To mute device, quickly press the ON/OFF button (orange light will turn on). Press the button again to un-mute the device (orange light will turn off).

TO SELECT GROUP/CHANNEL

- Different classrooms on the CSU campus require different wireless frequencies. See chart for more information.
- To select a GROUP/CHANNEL: Press and hold “select” button on the front of device until numbers in the front window blink. Press the “select” button quickly to change the GROUP or CHANNEL setting. To switch between GROUP or CHANNEL setting, press “select” button for 2 seconds.
- After 5 seconds of inactivity, the GROUP/CHANNEL display exits the change mode.

TO QUICK SYNC A MICROPHONE

- Open the battery pack flip door to expose the batteries and the SYNC sensor.
- Hold the SYNC sensor up to, and facing toward, the Shure mic receiver mounted in the podium, then push the round SYNC button on the front of the receiver until a green light next to the SYNC button turns on.
- The green light indicates that the receiver has properly auto Synced the mic to whatever group and channel the receiver is set to.